# 网迅科技DCB 配置用户手册

V1.0.0



北京网迅科技有限公司

2023 年09 月

版本 描述		
1.0.0	1、介绍了dcb 的修改,查看功能, pfc 及ets 的配置	
1.0.0	2、常见问题解决方法	2

### 1.开启dcb 和查看dcb 状态

1.1.开启dcb 命令

[root@localhost ~]# dcbtool sc enp2s0f0 dcb				
Command:	Set Config			
Feature:	DCB State			
Port:	enp2s0f0			
Status:	Successful			

### 1.2.查看dcb 状态

[root@localhost ~]# dcbtool gc enp2s0f0 dcb			
Command:	Get Config		
Feature:	DCB State		
Port:	enp2s0f0		
Status:	Successful		
DCB State:	on		

## 2.配置pfc

[root@localhost ~]# dcbtool sc enp2s0f0 pfc pfcup:11110000

## 3.配置ets

[root@localhost ~]# dcbtool sc enp2s0f0 pg up2tc:00001007 Command:Set ConfigFeature:Priority GroupsPort:enp2s0f0Status:Successful[root@localhost ~]# dcbtool sc enp2s0f0 pg pgpct:30,70,0,0,0,0,0

4.配置之后需要重启下lldpad 服务

[root@localhost ~]# systemctl restart lldpad

5.WH交换机端需要配置成intel-oui

dcb compliance intel-oui #若不配置,交换机端默认是IEEE 模式

## 6.遇到的问题

6.1Failed to connect to Ildpad - clif\_open: Connection refused

现象:

[root@localhost ~]#dcbtool gc enp2s0f0 dcb connect: Connection refused Failed to connect to lldpad - clif\_open: Connection refused

解决方法: 重启lldpad 服务和fcoe 服务

[root@localhost ~]# systemctl restart lldpad [root@localhost ~]# systemctl restart fcoe

重启上面两个服务之后就可以正常查看了

nost ~]# dcbtool gc enp2s0f0 dcb
Get Config
DCB State
enp2s0f0
Successful
on

6.2dcb 状态开启失败

现象:

	[root@locall Command: Feature: Port: Status: [root@locall Get Config	host ~]# dcbtool sc e Set Config DCB State enp2s0f0 Successful host ~]# dcbtool gc e	enp2s0f0 dcb <mark>on</mark> enp2s0f0 dcb Command:			
	Feature: Port: Status:		DCB State enp2s0f0 Successful			
		DCB State:	off			
_ 解}	央方法:					
	[root@localhost ~]# dcbtool sc dcbx v:force-cee Command: Set Config Feature: DCBX Version Status: Successful [root@localhost ~]# systemctl restart lldpad					
再	次查看dcb 状态就	是on 了:				
	[root@localhost ~]# dcbtool gc enp2s0f0 dcb Command: Get Config					
	Feature: Port: Status:		DCB State enp2s0f0 Successful			
		DCB State:	on			